

MAIN COMPONENT POWER TRANSMISSION

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
PTO Drive Assembly				Fasteners			
1	4850	Handle Grip	1	F004	1/4-20 Keps Nut		5
2	2358	Clutch Lever (Includes Item # 1)	1	F008	5/16-24 Keps Nut		2
3	5830-4	Grease Fitting (90 Deg.)	1	F009	5/16-18 Whiz Locknut		12
4	5214-2	Ball Joint (5/16-24) (Nylon Lined)	2	F012	3/8-16 Keps Nut		1
5	4358-1	Clutch Rod	1	F013	3/8-16 Whiz Locknut		3
6	5229	Extension Spring (1/2 x 2-1/4)	1	F020	5/16-18 ESNA Nut		1
7	2358-5	Clutch Actuator	1	F024	5/16-24 Jam Nut		2
8	5103-2	Pivot Bushing (5/16 ID)	2	F029	1/4-20 x 1/2 Hex Bolt		1
9	2358-6	5/16-18 x 1-3/4 Stud	2	F031	1/4-20 x 5/8 Hex Bolt		5
10	2349-2	Bearing Mount Plate	1	F034	5/16-18 x 3/4 Hex Bolt		5
11	2349-3	Switch Pivot Mount	1	F046	3/8-16 x 3-1/2 Hex Bolt		1
12	7407	Clevis Pin (3/16 x 1/2)	2	F091	5/16-18 x 5/8 Hex Bolt		1
13	2358-4	Clutch Actuator Link	2	F093	5/16-18 x 1 Hex Bolt		4
14	4358-5	Clutch Linkage Spring	1	F114	5/16-18 x 5/8 SQH Set Screw		1
15	2236	PTO Pulley (Includes Items # F075, F114 & F435)	1	F127	1/16 x 1/2 Cotter Pin		2
16	5268	Bearing W/Collar (3/4)	2	F163	5/16-18 x 3/4 SQH Set Screw		1
17	2274-6	PTO Drive Shaft (1")	1	F168	5/16 Split Lock Washer		1
	2274-5	PTO Drive Shaft Assembly	*	F170	5/16 x 1 x 7/64 Flat Washer (Zinc Plate)		1
18	7275-9	Quick Coupler Installation Tool	**	F178	1/4 x 1 Fender Washer		1
19	7275-16	Universal Joint Tube Assembly / Spline	1	F185	1/4 Int. Star Lock Washer/SS		1
20	2274-7	PTO Bearing Housing	1	F241	.375 x .875 x .10 Washer		2
21	4325-3	Clutch Stop	1	F336	3/8-16 Jam Nut		1
22	2325-1	Clutch Retainer	1	F388	3/8-16 x 2-1/2 Hex Bolt		1
23	2325-4	Idler Adjustment	1	F435	1/4 x 1/4 x 1-1/4 Key		1
24	2265	Bearing (20mm)	4				
25	2406-7	Pivot Shaft Spacer	1				
26	2236-1	Idler Pulley (4.5/AAA)	2				
27	7201-7	Inner Race (2-5/8)	1				
28	7201-3	DU Bearing	2				
29	2230	Engine PTO Belt/Set (3)	1				
30	2236-4	Idler Pulley Shaft	1				
31	2325-3	Idler Adjuster	1				
32	2325-2	Tensioner Bolt	1				
33	5830-3	Grease Fitting (45 Deg.)	1				
34	2325	Idler Arm (Includes Item # 33)	1				
35	5841	Retainer Washer (3/8 x 1-1/4)	1				
36	2410	Mechanical Clutch	1				

* Service Part Only

** The Quick Coupler Installation Tool is used to assist the installation of the Quick Coupler Tube and PTO Shaft connection by holding the disconnect ring in the retracted position when joined to the tractor spline shaft on the PTO Drive Shaft.

Effective Date 03-31-08

Use only genuine **Walker®** replacement parts.

Use only genuine **Walker®** replacement parts.