

STEERING CONTROL ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Steering Lever & FSC Assemblies				Transmission Spring Assemblies			
1	5862	FSC Knob	1	36	4199	Transmission Spring Assembly (Includes Items # 37-43, F004, F032, F320 & F352)	*
2	4170	FSC Lever Assembly (Includes Item # 4)	*	37	4552	Ball Joint (1/4-28)	2
3	2170-1	Step Washer	1	38	5194	Plunger Sleeve	2
4	5830	Grease Fitting	1	39	5192-2	Spring Plunger (Female)	2
5	5214-5	Ball Joint (5/16-24/LH) W/O Stud	1	40	5193	Washer (3/4 x 1 x .085)	2
6	4213	Control Rod	1	41	6191	Spring Slide (4-3/4)	2
7	5214-4	Ball Joint (5/16-24) W/O Stud	1	42	5195	Compress Spring (1 x 5-1/8)	2
8	5214-3	Ball Joint (5/16-24 LH) (Nylon Lined)	2	43	6196	Spring Slide Cap	2
9	4173	Control Rod	2	Fasteners			
10	2212	Transmission Control Arm Stop	2		F003	1/4-28 Hex Nut	2
11	2212-2	Transmission Control Arm, RH	1		F004	1/4-20 Keps Nut	6
12	2025-10	TWHCS 5/16-24 x 1.0 (Patch)	2		F005	1/4-20 ESNA Nut	2
13	5214-2	Ball Joint (5/16-24) (Nylon Lined)	2		F008	5/16-24 Keps Nut	4
14	2212-1	Transmission Control Arm, LH	1		F009	5/16-18 Whiz Locknut	6
15	2451-1	Steering Pivot Shaft With Stop	1		F024	5/16-24 Jam Nut	3
16	5830-3	Grease Fitting (45 Degree)	1		F032	1/4-20 x 3/4 Hex Bolt	2
17	8201-3	Fiberglide Bearing	4		F035	5/16-18 x 1-1/4 Hex Bolt	1
18	2451-3	Speed Control Actuator, LH (Includes Items # 16 & 17)	1		F059	3/8 Wave Spring Washer	1
19	5146	10mm Ball Stud	4		F093	5/16-18 x 1 Hex Bolt	2
20	2215-1	Steering Lever Dampener	2		F121	5/16-18 x 3/8 x 1 SHL Bolt	1
21	2451-2	Speed Control Actuator, RH (Includes Items # 17 & 22)	1		F146	1/4-20 Jam Nut	2
22	5830-4	Grease Fitting (90 Deg.)	1		F167	5/16-18 Hex Nut	1
23	4451-4	FSC Friction Actuator	1		F183	.312 x .700 x .074 Washer	2
24	4219	Extension Spring (3/4 x 6-1/2)	1		F188	1/4-20 Self-Locking Nut	4
25	5850-2	Handle Grip, Foam (5-1/2)	2		F192	3/8-24 Self-Locking Nut	1
26	5453-20	Steering Lever Handle (+1") Adjustable / SS (Includes Items # 25, F188, F198 & F345)	2		F198	.250 x .625 x .040 Washer, SS	2
27	4452-4	Steering Lever Tube W/Tab	2		F209	.765 ID x 1.312 OD x .032 Washer	2
28	5450	D-Clip	2		F211	1/4-20 x 7/8 Hex Bolt	1
29	5222	Extension Spring (1/2 x 3-1/4)	2		F320	1/8 x 3/4 Split Spring Pin	2
30	4452-6	Steering Pivot (1/4-20 x 1-1/2)	2		F345	1/4-20 x .770 Knurled Bolt	4
31	4142-1	FSC Cam	1		F352	5/32 x 1 Heavy Duty Roll Pin	2
32	5141	FSC Friction Washer (1-1/2 x 3/8 x 1/16)	1		F373	5/16-24 Hex Nut, LH	3
33	4142-2	FSC Friction Washer (1-1/2 x 1-1/32 x 1/16)	1		F385	1/4 x 1-1/4 Roll Pin	1
34	9704-3	Pivot Rod Bushing, Plastic	2		F386	5/16-18 x 1-1/2 x 3/8 Shoulder Bolt	1
35	2451-4	Steering Shaft Spacer	1		F391	1/4-20 x 1/2 Set Screw, SS	2
					F407	Belleville Washer 3/8 x 1.187, SS	1
					F427	5/16-18 Flange Nut	1
				* Service Part Only			

Use only genuine **Walker®** replacement parts.

Effective Date 03-31-08

Effective Date 03-31-08

