


MAIN COMPONENT POWER TRANSMISSION

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
PTO Drive Assembly				51	5214-2	Ball Joint (5/16-24) (Nylon Lined)	1
1	4850	Handle Grip, Black	1	52	7226	Compression Spring (3/4 x 2-1/2)	1
2	2358-1	Clutch Lever, MBS (Includes Items # 1 & 3)	1	53	7380	Knuckle Joint	1
3	5830-3	Grease Fitting (45 Deg.)	3	Fasteners			
4	4303-7	Clutch Actuator Bolt (5/16)	1		F004	1/4-20 Keps Nut	5
5	2306-2	Oilite Flanged Bushing	2		F008	5/16-24 Keps Nut	1
6	5830	Grease Fitting	2		F009	5/16-18 Whiz Locknut	13
7	2325-7	Clutch Arm (Includes Items # 5 & 6)	1		F010	5/16-24 ESNA Nut	1
8	5221-1	Extension Spring (3/4 x 5)	1		F012	3/8-16 Keps Nut	1
9	2358-10	Clutch Rod	1		F013	3/8-16 Whiz Locknut	2
10	5214-4	Ball Joint (5/16-24) W/O STD	2		F024	5/16-24 Jam Nut	2
11	2358-9	Clutch Pivot Base	1		F029	1/4-20 x 1/2 Hex Bolt	1
12	5214-13	Ball Joint (3/8)	1		F031	1/4-20 x 5/8 Hex Bolt	13
13	2358-8	Adjustor Brace	1		F034	5/16-18 x 3/4 Hex Bolt	9
14	7775-6	Wire Lock Pin (2-1/2")	3		F035	5/16-18 x 1-1/4 Hex Bolt	3
15	2302-4	Right Hand Shoe	1		F049	5/16 SAE Washer	2
16	2302-7	Upper Shoe, LH	1		F058	1/4 Wave Spring Washer	6
17	2302-3	Left Hand Shoe	1		F060	AN960516 Washer	2
18	2349-7	Bearing Mount	1		F061	1/4 Star Lock Washer	1
19	2406-5	Spacer	1		F069	3/32 x 1/2 Cotter Pin	1
20	2236-5	PTO Pulley (4.5/AAA)	1		F091	5/16-18 x 5/8 Hex Bolt	1
21	2274-9	Collar (1")	2		F104	1/4-20 x 3/4 PFH Bolt	2
22	2274-8	Bearing (1")	2		F120	AN960416 Washer	8
23	2359-1	Brake Band / Guard Mount	1		F146	1/4-20 Jam Nut	1
24	7775-8	Wire Lock Pin (4")	1		F149	1/4 x 1/4 x 1-1/2 Key	1
25	2302-5	PTO Shoe	1		F168	5/16 Split Lock Washer	1
26	2410-2	Drive Shaft	1		F170	5/16 x 1 x 7/64 Flat Washer (Zinc Plate)	1
27	7275-9	Quick Coupler Installation Tool	**		F171	5/16-18 x 3/8 Set Screw	1
28	7275-16	Universal Joint Tube Assembly / Spline	1		F178	1/4 x 1 Fender Washer	1
29	2274-7	PTO Bearing Housing	1		F182	1/4 x 5/8 x 1/8 Washer	1
30	2274-10	PTO Drive Shaft Assembly (Includes Items # 21, 22, 26 & 29)	*		F211	1/4-20 x 7/8 Hex Bolt	1
31	2302-6	Shoe Mount, LH	2		F217	7/16-14 Hex Nut	2
32	2358-7	Clutch / Pivot Stop MBSSD	1		F218	7/16 Split Lock Washer	2
33	7523-2	Clevis Pin W/Hole (1/4 x 5/8)	1		F219	7/16-14 x 1-1/4 Hex Bolt	2
34	4359-2	Brake Band Link, Rear	1		F241	.375 x .875 x .10 Washer	1
35	8304	Brake Band (14-1/2)	1		F255	5/16-18 x 1-1/2 Hex Bolt	4
36	4359-1	Brake Band Link, Front	1		F298	3/8-24 Jam Nut	1
37	2410-2	Drive Shaft	1		F350	1/4-20 LP Nylock	9
38	2265	Bearing (20mm)	4		F389	3/8-16 x 2-3/4 Hex Bolt	1
39	2406-7	Pivot Shaft Spacer	1		F431	1/4-20 x 3-1/2 Hex Bolt	1
40	2236-1	Idler Pulley (4.5/AAA)	2		F435	1/4 x 1/4 x 1-1/4 Key	2
41	2230	Engine PTO Belt / Set (3)	1		F450	Washer 5/8 x 2 x 1/4	1
42	2236-6	Pulley (Includes Items # F149 & F171)	1		F452	5/8-18 Nylon Locknut	1
43	2236-4	Idler Pulley Shaft	1		F473	5/16-18 x 5 Hex Bolt	1
44	7201-3	Fiberglide Bearing	2		F476	3/8-16 x 6-1/2 Hex Bolt	1
45	7201-9	Inner Race	1		F484	Washer .370 ID x 1.0 OD x .120	2
46	2359-2	Clutch Engagement (Includes Items # 3 & 44)	1	* Service Part Only			
47	2349-6	Flanged Bearing (Includes Item # 6)	1	** The Quick Coupler Installation Tool is used to assist the installation of the Quick Coupler Tube and PTO Shaft connection by holding the disconnect ring in the retracted position when joined to the tractor spline shaft on the PTO Drive Shaft.			
48	4302-2	Shoe Mount	1				
49	7377	Plastic Washer (1 x .438 x .025)	2				
50	7378	Pivot Bearing (7/16 x 9/16)	1				

Use only genuine **Walker®** replacement parts.

Effective Date 09-15-10

MAIN COMPONENT POWER TRANSMISSION



Effective Date 09-15-10

Use only genuine **Walker®** replacement parts.