

TRACTOR DECALS

ITEM NO.	PART NO.	DESCRIPTION	LOCATION	NO. REQ'D SD
Walker Product and Operation Decals				
1	2802-4	RH Fender	Body, RH near Seat	1
2	5800-6	Decal, Walker 6-3/4"	Rear Body (one on each side)	2
3	2010-17	Fuel Transfer	Transfer Mount, LH	1
4	2802-5	LH Fender	Body, LH near Seat	1
5	9804-1	Axle Lockout	Hydro Mount Plate	2
6	2351-8	Decal, Belt Tensioner	Hydro Mount Plate	1
7	5856	Made in USA	Body	1
8	5803	Walker Manufacturing Logo	Body	1
Danger Decals Warning Decals Caution Decals				
9	8600-5	Caution, Engine Exhaust	Rear Body	1
10	5844-2	Warning, Electric System	Battery Hold-Down Bar	1
11	8600-12	Danger, Engine Exhaust	Engine, LH Side	1
12	2107-4	Decal, Belt Routing	Rear Body, Underside	1
13	8600-2	Danger, Rotating Components	Air Cleaner Bracket	1
Maintenance Decals				
14	5082-5	Fuel Recommendations	Rear Body (one on each side)	2
15	2105-10	RH Decal, 29 HP	Rear Body, RH Side	1
16	2105-11	LH Decal, 29 HP	Rear Body, LH Side	1
17	5855	Important, Engine Cooling	Engine	1
18	2807-2	Decal, Systems Warning	Body	1
Option Decals (applied only to units with corresponding Options installed)				
19	5877	Lights, On-Off	Body	1

NOTE: All parts requiring decals are shipped with decals applied.

TRACTOR DECALS

