

MAIN COMPONENT POWER TRANSMISSION

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Safety Switch Actuator Assembly				27	9050	PTO Gearbox	1
1	9744	Safety Switch Lever, RH	1	28	9303	PTO Mount Side Plate, LH	1
2	5103-2	Pivot Bushing (5/16 ID)	2	29	9304	PTO Mount Side Plate, RH	1
3	9742-2	Plastic Bushing (5/8 x 3/8)	1	30	9309	5/16 Tab Lock Washer	2
4	9742-1	Compression Spring (3/8 x 5/8)	1	31	9480	Belt Guide (Includes Item # F009)	1
5	9742	Safety Switch Actuator	1	32	9301	Brake Band	1
6	9743	Safety Switch Lever, LH	1	33	9236	PTO Pulley (5/3V) (Includes Items # 34, F067, F168 & F181)	1
PTO Drive Assembly				34	9051	5/8 x 1-1/8 x 3/8 Washer	1
7	9230	PTO Drive Belt	1	35	9306	Front Pivot, PTO Gearbox	1
8	7380-5	Knuckle Joint (3/8 ID)	1	Fasteners			
9	7377	Plastic Washer (7/16 x 1 x .025)	2	F005	1/4-20 ESNA Nut	2	
10	7378	Pivot Bearing (7/16 x 9/16)	1	F007	5/16-18 Jam Nut	1	
11	5830	Grease Fitting	2	F009	5/16-18 Whiz Locknut	5	
12	9358	Clutch Lever (Includes Item # 11)	1	F010	5/16-24 ESNA Nut	1	
13	5830-4	Grease Fitting (90 Deg.)	1	F012	3/8-16 Keps Nut	2	
14	9130-1	Clutch Actuator Spring	1	F013	3/8-16 Whiz Locknut	2	
15	9130-2	Clutch Actuator Rod	1	F020	5/16-18 ESNA Nut	8	
16	9130-3	Clevis	1	F026	10-24 x 1/2 PPHMS	1	
17	9130-4	5/16 x 1 Clevis Pin	1	F029	1/4-20 x 1/2 Hex Bolt	3	
18	9359	Lower Clutch Pivot	1	F034	5/16-18 x 3/4 Hex Bolt	2	
19	9359-1	Pivot Mount, Clutch (Includes Item # 11)	1	F049	5/16 SAE Washer	4	
20	9307	Link, PTO Actuator	2	F061	1/4 Star Lock Washer	1	
21	5221	Extension Spring (3/4 x 4)	1	F093	5/16-18 x 1 Hex Bolt	6	
22	9306-1	Plastic Bushing, Rear Pivot	4	F111	1/8 x 3/4 Cotter Pin	1	
23	9302	PTO Gearbox Mount Plate	1	F151	3/8-16 x 7/8 Hex Bolt	4	
24	9305-1	Plastic Bushing, Front Pivot	8	F168	5/16 Split Lock Washer	1	
25	9305	Swingarm, PTO Gearbox	2	F178	1/4 x 1 Fender Washer	1	
26	7275-16	U-Joint Tube Assy, Spline	1	F181	5/16-24 x 1 Hex Bolt	1	
				F235	5/16-18 x 2-1/2 Hex Bolt	4	
				F371	5/16-18 x 6 Hex Bolt	2	

MAIN COMPONENT POWER TRANSMISSION

